

OUTFIT™ SEATING

Operating Instructions Conference Chair



P.O. Box 8400
Green Bay, WI 54308-8400
Tel 920.468.8100 • Fax 920.468.2633
©OEI 2010 Litho in USA Code OE-60895/VL0210

Obtaining Maximum Benefits From Your Outfit™ OEI56 Conference Chair

A. Tilt-Lock Adjustment

To lock your chair in the upright position, move chair into upright position, push the lever beneath the seat in toward the center of the chair.

To unlock the upright lock, pull the lever beneath the seat out away from your body.

B. Seat Height Adjustment

To lower the seat, remain seated in chair and raise the lever. To raise the seat, lift body weight slightly off the chair and raise the lever.

C. Tilt-Tension Adjustment

Turn the knob clockwise to increase tension and counterclockwise to decrease tension.

